



SINT Srl

ENGINEERING CONSULTING AND SOFTWARE

XGSLab™

SCIENCE FOR ENGINEERING

THE STATE OF THE ART OF THE
ELECTROMAGNETIC SIMULATION FOR
POWER SYSTEMS, GROUNDING,
INTERFERENCE AND LIGHTNING

FAQ



ELECTROMAGNETIC SIMULATION FOR
POWER SYSTEMS, GROUNDING, INTERFERENCE AND LIGHTNING

1995 – 2024
(Release 2024.1.1- 05/24)

FAQ
(Frequently Asked Questions)

ALL RIGHTS RESERVED

This document, or parts thereof, may not be reproduced in any form, by any method, for any purpose without the written permission of SINT Srl.

SINT Srl reserves the right to revise and improve its products as it sees fit.

This document describes the state of this product at the time of its publication, and may not reflect the product at all times in the future. Moreover, due to the continuous evolution of the XGSLab software, some screens or numerical obtained by last XGSLab version could be slightly different from those in this document.

The software described in this document is delivered under license agreement.

SINT Srl - Via Cristoforo Colombo, 106 - 36061, Bassano del Grappa (VI) – Italy (www.xgslab.com)

Possession or use of the XGSLab software is authorized only pursuant to a valid written license agreement from SINT Srl. Before using XGSLab please read the document “End User License Agreement “.

While every precaution has been taken in the preparation of this User’s Guide, SINT Srl assumes no responsibility for errors or omissions, or for damages resulting from the use of the information contained herein.

TRADEMARK

Attention is drawn to the possibility that some of the elements of this document may be the subject of patent rights.

SINT Srl shall not be held responsible for identifying any or all such patent rights.

Windows is a registered trademark of Microsoft.

AutoCAD is a registered trademark of Autodesk.

Google Earth is a registered trademark of Google.

Other Trademarks are used in this document in an editorial fashion with non intention of infringement.

All trademarks are the legal property of their registered owners.

REVISION RECORD

Date	Release	Note
October 2012	4.0.1	New module GSA
September 2014	5.0.1	New module GSA_FD
March 2015	6.0.1	New module XGSA_FD
March 2017	7.0.1	New module XGSA_TD
July 2017	8.0.1	Multilayer Soil Model
November 2017	8.1.1	IEC Standard
February 2018	8.2.1	Low Frequency Breakdown Solution + Draw Tools
April 2018	8.3.1	Higher Robustness Calculation Algorithms + Graphical Outputs
January 2019	8.3.2	General improvements + New module NETS predisposition
February 2019	9.0.1	New module NETS
June 2019	9.1.1	Zig-Zag Transformer + Pipe Type Cable + Fragmentation Rules
September 2019	9.2.1	XGSA_TD extended to 100 MHz + Corona Effect Tool
November 2019	9.3.1	General improvements
March 2020	9.4.1	Increasing in computing speed + Imperial Units
July 2020	9.5.1	Seasonal Analysis + Export to Google Earth™
February 2021	9.6.1	Libraries refactoring + New viewer based on OpenGL
September 2021	10.0.1	New module SHIELD + New CAD based on OpenGL
May 2022	10.1.1	Screened Conductors + Multicores Cables
December 2022	10.2.1	New Scheduling Tool + Unlimited Elements number
June 2023	10.3.1	Electromagnetic Forces + Surge Protective Devices
June 2024	2024.1.1	New Vector Graphic Interface

TABLE OF CONTENTS

1. PURCHASING FAQ.....	4
1.1 HOW CAN I HAVE A QUOTE AND PLACE AN ORDER?	4
1.2 IS XGSLAB AVAILABLE AS ANNUAL SUBSCRIPTION?.....	4
1.3 CAN I UPDATE MY LICENSE XGSLAB FROM AN OLD VERSION TO THE LATEST ONE?	4
1.4 CAN I UPGRADE MY LICENSE XGSLAB TO A HIGHER PRODUCT EDITION?	4
1.5 WHEN DOES MY XGSLAB LICENSE EXPIRE IF I DON'T RENEW IT?	4
1.6 WHAT PAYMENT METHODS DO YOU ACCEPT?	4
1.7 HOW DO I RECEIVE THE INVOICE FOR MY PURCHASE?	4
1.8 DO YOU ACCEPT PURCHASE ORDERS?	5
1.9 WHAT CURRENCY DO YOU ACCEPT?	5
1.10 HOW DO I RENEW MY SUBSCRIPTION OR SUPPORT?	5
1.11 IS IT POSSIBLE TO AUTO-RENEW THE SUBSCRIPTION?	5
1.12 ARE TAXES INCLUDED IN THE PRICE?	5
2. LICENSING FAQ	6
2.1 HOW IS XGSLAB DELIVERED?	6
2.2 HOW DO I OBTAIN MY CREDENTIALS FOR DOWNLOAD THE SOFTWARE?	6
2.3 DOES XGSLAB REQUIRE A PROTECTION KEY?	6
2.4 DOES XGSLAB CAN BE USED IN REMOTE WAY?	6
2.5 CAN I ACTIVATE XGSLAB ON A MACHINE WITHOUT AN INTERNET CONNECTION?.....	6
2.6 DO YOU COLLECT ANY PERSONAL INFORMATION DURING ACTIVATION?.....	7
2.7 CAN I INSTALL XGSLAB ON MORE THAN ONE MACHINE?	7
2.8 WHAT ARE THE XGSLAB HARDWARE AND SOFTWARE REQUIREMENTS?	7
2.9 DOES XGSLAB CAN WORKS ON WINDOWS 64 BIT?	8
2.10 WHAT IS XGSLAB THE WARRANTY PERIOD?	8
2.11 WHAT CAN I DO IF I NEED A LICENSE FOR AN OLD VERSION OF XGSLAB?	8
2.12 DOES XGSLAB INCLUDES A SUPPORT AND MAINTENANCE SERVICE?	8
2.13 HOW ARE BUGS HANDLED AND FIXED?	9
2.14 ARE THERE SPECIAL OFFERS FOR RESEARCH?	9
3. SUPPORTING FAQ	10
3.1 ARE TRAINING COURSE AVAILABLE FOR XGSLAB?.....	10
3.2 WHICH ARE THE STANDARDS USED BY XGSLAB?	10
3.3 WHAT IS THE APPLICABLE FREQUENCY RANGE OF XGSLAB?	11
3.4 DOES XGSLAB CONSIDER MULTILAYER SOIL MODEL?	11
3.5 WHEN SEASONAL ANALYSIS IS IMPORTANT?	12
3.6 WHY THE DOUBLE LAYER SOIL MODEL IS ANYWAY IMPORTANT?	13
3.7 WHEN IT IS IMPORTANT TO CONSIDER SOIL PARAMETERS FREQUENCY DEPENDENCE?	15
3.8 WHY IT IS IMPORTANT A MODEL THAT CONSIDERS BOTH SELF AND MUTUAL IMPEDANCES?	15
3.9 IS IT POSSIBLE MODELING THE SOIL USING SOIL RESISTIVITY MEASUREMENTS?.....	16
3.10 WHAT THE MESSAGES "TOO SHORT ELEMENT" AND TOO LONG ELEMENT" MEAN?.....	16
3.11 CAN I CONSIDER SOIL IONIZATION EFFECTS?	16
3.12 CAN I CALCULATE AN INTERFERENCE WITH SYSTEMS AT DIFFERENT FREQUENCY?	17
3.13 CAN I CALCULATE AN INTERFERENCE BY PARTS AND THEN SUPERPOSE THE EFFECTS?.....	17
3.14 DOES XGSLAB CONSIDER THE END EFFECTS?	18
3.15 ON WHICH CALCULATION METHOD XGSLAB IS BASED?	18
3.16 IS IT POSSIBLE IMPEDANCE TO EARTH INCREASES WHEN SYSTEM SIZE INCREASES?	19
3.17 IS IT POSSIBLE TO REPRESENT CONCRETE ENCASED CONDUCTORS?.....	20
3.18 CAN I CONSIDER ADDITIONAL RESISTANCES IN IEEE STANDARDS LIMITS?	21
3.19 CAN I USE LIBRARIES IN MY COMPUTER IN OTHER COMPUTERS?	23
3.20 WHAT IS THE MAXIMUM NUMBER OF LAYERS IT IS POSSIBLE TO CALCULATE?.....	24
3.21 CAN I DO CALCULATIONS IN THE TIME DOMAIN USING AN EQUIVALENT FREQUENCY?	26
3.22 HOW CAN I PROPERLY SET THE "RAM SAVING" THRESHOLD?	27
3.23 WHAT IS THE MAXIMUM HEIGHT OF STRUCTURES SHIELD CAN CONSIDER?	28
4. DEMO FAQ	30
4.1 CAN I HAVE A WEB BASED PRESENTATION OR A DEMO VERSION?	30
4.2 HOW TO ACTIVATE CAMEYO ONLINE DEMO?	30
4.3 HOW TO IMPORT EXTERNAL FILES IN THE CAMEYO ONLINE DEMO?	32

1. PURCHASING FAQ

Get more information about ordering, payments, and product delivery.

1.1 HOW CAN I HAVE A QUOTE AND PLACE AN ORDER?

XGSLab includes many modules and each module is available with several profiles. For this reason, it is important asking for a customized offer to sales@xgslab.com. The offer will include instructions useful to take the order.

1.2 IS XGSLAB AVAILABLE AS ANNUAL SUBSCRIPTION?

XGSLab is available as Annual Subscription and formally Perpetual license (10 years after last support expiration date). In the future the Annual Subscription will be the preferred license form.

1.3 CAN I UPDATE MY LICENSE XGSLAB FROM AN OLD VERSION TO THE LATEST ONE?

It is possible to update a license only within the expiration period for both options, subscription or purchase. New versions are available on our helpdesk, and only during subscription or support validity period our helpdesk will be accessible.

1.4 CAN I UPGRADE MY LICENSE XGSLAB TO A HIGHER PRODUCT EDITION?

It is possible to upgrade a license in any time.

In case of annual subscription within the expiration period the cost of the residual period of the license before upgrading will be subtracted.

In case of purchase the new support expiration will be 1 year after upgrade and will be valid also for license before upgrading. The cost for the support extension of the license before upgrading must be added to the cost of the upgrade.

1.5 WHEN DOES MY XGSLAB LICENSE EXPIRE IF I DON'T RENEW IT?

For subscription-based licenses, you can use the license until the subscription period ends.

For purchased licenses, the license is effectively perpetual, although it's important to note that in the context of software programs, nothing truly lasts forever. In the case of XGSLab, "perpetual" means the program can be used for 10 years after the last update, and then an additional 10 years after the last support expiration.

It's reasonable to assume that after 10 years without updates, XGSLab may become obsolete or unsupported by future operating systems and graphics technologies.

1.6 WHAT PAYMENT METHODS DO YOU ACCEPT?

We accept wire transfers and credit cards.

1.7 HOW DO I RECEIVE THE INVOICE FOR MY PURCHASE?

The invoice will be sent when payment is successfully completed (unless otherwise agreed).

1.8 DO YOU ACCEPT PURCHASE ORDERS?

Yes, we do.

We accept purchase orders from existing customers.

Purchase orders from newly registered customers are subject to a preliminary checking before acceptance.

1.9 WHAT CURRENCY DO YOU ACCEPT?

We set prices and accept payments for our products only in EUR.

1.10 HOW DO I RENEW MY SUBSCRIPTION OR SUPPORT?

You will receive a first reminder 60 days before expiration of subscription or support with instructions for renewal.

You will receive a second reminder the day of expiration of subscription or support.

We strongly suggest to renew subscription or support before the expiration.

In case of purchase, the cost for support renewal is increased of 50% if the support period has been expired for more than 6 months.

1.11 IS IT POSSIBLE TO AUTO-RENEW THE SUBSCRIPTION?

Auto-renewal of subscriptions is available. The auto-renewal period is virtually perpetual, you can cancel the auto-renewal by sending an email 90 days before the expiration date.

1.12 ARE TAXES INCLUDED IN THE PRICE?

No. Product prices do not include any national, state or local sales, use, value added or other taxes.

You will have to pay such taxes, if due.

2. LICENSING FAQ

Get more information about license profile.

2.1 HOW IS XGSLAB DELIVERED?

The software and its documents are delivered electronically only.

If the software is protected by a software key there are no physical shipment.

If the software is protected by a hardware key, the hard lock will be delivered via courier.

2.2 HOW DO I OBTAIN MY CREDENTIALS FOR DOWNLOAD THE SOFTWARE?

After placing the order, you will receive a welcome mail with download credentials, expiration date and software download instructions.

2.3 DOES XGSLAB REQUIRE A PROTECTION KEY?

Yes, XGSLab requires a protection key.

The single user versions of XGSLab are protected with a software or hardware key.

The network versions of XGSLab are protected only with a software key.

The software key is sent via email. Delivery time is usually in the range 1 – 2 working days.

The hardware key is shipped via courier. Delivery time is usually in the range 1 – 4 working days.

In the future hardware keys will become obsolete and the software keys will be the preferred protection form.

The program can be downloaded from our helpdesk web site. Download credentials are usually sent in 1 – 2 working days.

All deadlines refer to the purchase order date.

2.4 DOES XGSLAB CAN BE USED IN REMOTE WAY?

We do not introduce limitations in using XGSLab in remote way using a VPN (Virtual Private Network) and Virtual Desktop but this use is possible only with a network key.

Stand alone key does not allow this use and in this case, the following error message appear.




Figure 2-1: Error message in case of use of stand alone key in remote way

2.5 CAN I ACTIVATE XGSLAB ON A MACHINE WITHOUT AN INTERNET CONNECTION?

Yes, this is possible.

2.6 DO YOU COLLECT ANY PERSONAL INFORMATION DURING ACTIVATION?

No. The information required includes the version of the software, the end user's user account, product ID information, a machine ID, and the internet protocol address of the device.

2.7 CAN I INSTALL XGSLAB ON MORE THAN ONE MACHINE?

In case of single user software key, the program can run only on the PC where the software is installed.

In case of single user hardware key, the program can be installed in an arbitrary number of PCs but it will run only on the PC where the key is plugged.

In case of network software key, the program can run and then can be installed on any PC connected to the local network where the key is installed. The number of concurrent Users depend on the specific license profile.

2.8 WHAT ARE THE XGSLAB HARDWARE AND SOFTWARE REQUIREMENTS?

XGSLab is designed to operate on a personal computer (PC) having the following software and hardware requirements.

Software requirements:

Operating system: Windows® 8 or later, Windows® 10 or later are anyway suggested (Windows® 11 included)

Microsoft® .NET Framework 4.8 installed

Note for other operative systems (MacOS, UNIX ...):

- XGSLab can works also on other operating systems using virtual machine with MS Windows® installed

Recommended Hardware requirements:

- CPU: Intel Core i5 for basic versions, Core i7, multi-core or more for higher versions
- Platform: 32- or 64-bit
- RAM: depending on module and maximum elements or cells number (see below)
- Hard Drive: 1 GB free space
- Monitor resolution: 1280x1024 pixels, 1920x1080 pixels (full HD) or more
- Port for protection key: USB 2.0 or USB 3.0
- OpenGL requires a Graphic Device that supports OpenGL 4.4 or upper (check your Graphics Card specifications for details)

The entire calculation process runs on the CPU and does not use any GPU features, so the graphics driver does not affect calculation performance. XGSLab uses parallel computing and some processes can be executed simultaneously, so multi-core CPUs can offer visible advantages in calculation performance, at least with a core number up to about 40.

Essentially, the calculation speed grows with the product "cores number * clock frequency".

Some multi-core CPUs have a different clock frequency for cores, in such cases previous rule is not valid.

The vector graphic OpenGL is available only for 64 bit version.

For the *GSA* modules, the following RAM hardware requirements should be considered. As the maximum elements number is limited depending on the license profile, the following RAM requirements are suggested:

- Models with up to 2000 elements: at least 4 GB
- Models with up to 5000 elements: at least 4 GB for GSA and 12 GB for *_FD and XGSA_TD
- Models with up to 16000 elements: at least 20 GB for GSA and 64 GB for *_FD and XGSA_TD
- Models with more than 16000 elements: depending on the available RAM as in the figure below (note the log-log scale)

The following figure shows the RAM requirements as a function of the module and maximum elements number.




Figure 2-2: RAM requirements

2.9 DOES XGSLAB CAN WORKS ON WINDOWS 64 BIT?

Starting from version 10.1, XGSLab id distributed only as 64 bit.

The 64 bit version is fast in calculation and it can manages all available memory.

2.10 WHAT IS XGSLAB THE WARRANTY PERIOD?

Like all purchasable software, we do not provide any warranty. In essence, we provide the software -as is-. To be absolutely certain of what we do or do not provide, please refer to the EULA (End User License Agreement).

2.11 WHAT CAN I DO IF I NEED A LICENSE FOR AN OLD VERSION OF XGSLAB?

Only last and penultimate version of XGSLab are available for download.

Clients who do not intend to renew the support service must save a copy of the latest downloaded version.

2.12 DOES XGSLAB INCLUDES A SUPPORT AND MAINTENANCE SERVICE?

XGSLab includes 12 months of support period.

Support service includes software update and maintenance support and Regular Engineering Applications support.

Software update and maintenance support includes new release, software patches and installation support.

Regular Engineering Applications support includes advice on how best to apply XGSLab to specific engineering problem.

Support requests are normally processed within one business day. Support is not available on Saturday and Sunday and during local National holidays. Moreover, Support will be limited during the Christmas period and the two central weeks of August due to Summer holidays.

Support requests must be addressed to “support@xgslab.com”.

Support via phone, or chat is not provided.

The support period may be renewed on an annual basis for periods of 1, 2 or 3 years.

Support is included in Annual Subscriptions during the validity period.

2.13 HOW ARE BUGS HANDLED AND FIXED?

Bugs can be notified by Users by using the email support@xgslab.com. Usually, it is important to add in email content screenshots and any other useful information and when possible the “xgslab” file.

As for bugs fixing, there are no general rules, it depends on the severity of the issue, whether there is a temporary workaround, etc. In most cases, you will be able to get a software patch from our support team. Sometimes, there is no possibility of a software patch, and you will have to wait for the next release.

2.14 ARE THERE SPECIAL OFFERS FOR RESEARCH?

Yes, XGSLab is available with a profile Research at a very special price.

The offer is limited to qualified academic, government and non-profit organizations and the only non-commercial use of the software is allowed. A certification is required to determine if the special price is applicable.

3. SUPPORTING FAQ

Get more information about technical questions.

3.1 ARE TRAINING COURSE AVAILABLE FOR XGSLAB?

Training course are for XGSLab Clients only and usually Web-Based.

We are working to a complete certified training course path (XGSLab ACADEMY) divided in 3 levels:

- Level 1: Preliminary + Grounding + Fault Current Distribution (already available)
- Level 2: Electromagnetic Interference and Fields + Lightning and Transients + Lightning Shielding
- Level 3: Advanced Applications and Knowledge

Each course will be divided in modular sessions.

Web-based courses are usually appreciated by customers because effective and cheap.

Furthermore, you can count on a complete and clear User's Guide with some very useful Tutorials and Videos.

3.2 WHICH ARE THE STANDARDS USED BY XGSLAB?

XGSLab is based on physic laws and uses standard only in some specific circumstance, for instance.

Touch and Step Voltages limits:

- International standard: IEC/TS 60479-1:2005
- International standard: IEC/TS 60479-1:2018
- European standard: HD 637 S1:1999
- European standard: EN 50522:2010
- European standard: EN 50522:2022
- USA standard: IEEE Std 80-2000
- USA standard: IEEE Std 80-2013

Conductor Sizing:

- European standard: HD 637 S1:1999
- European standard: EN 50522:2010
- European standard: EN 50522:2022
- USA standard: IEEE Std 80-2000
- USA standard: IEEE Std 80-2013

Split Factor:

- European standard: HD 637 S1:1999
- European standard: EN 50522:2010
- European standard: EN 50522:2022
- USA standard: IEEE Std 80-2000
- USA standard: IEEE Std 80-2013

Lightning Shielding:

- International standard: IEC 62305-3:2010 (equal to EN 62305-3:2010)

– USA standard: IEEE Std 998-2012

Reference Standards considered by XGSLab are accepted in many countries in the World.

3.3 WHAT IS THE APPLICABLE FREQUENCY RANGE OF XGSLAB?

XGSLab can be applied in a frequency range from DC to about 100 MHz depending on the soil resistivity.

In any case, a limit of a few tens of MHz is conservative and should not be understood in an absolute sense.

This limit means that starting from a few tens of MHz, calculation accuracy gradually decreases.

The frequency range from DC to a few tens of MHz contains all power system frequencies, and the most significant frequency spectrum of the electromagnetic transient as represented in the following figure.

Corona effects are partially out of the application range.




Figure 3-1: Frequency spectrum of electromagnetic phenomena

3.4 DOES XGSLAB CONSIDER MULTILAYER SOIL MODEL?

Yes, XGSLab considers the multilayer soil model.

The implemented algorithm is powerful and rigorous and can consider a multilayer soil model with an arbitrary number of layers without constraints (for instance on layer thickness multiple of the thinner layer).

The choice of the soil model is crucial in electromagnetic simulations and in particular in the grounding systems analysis. There is much literature about the criteria to set an appropriate soil model which can be used to predict the performances of a grounding system.

XGSLab allows to use uniform, multilayer and multizone soil models.

A uniform soil model should be used only when there is a moderate variation in apparent measured resistivity both in vertical and horizontal direction but, for the majority of the soils, this assumption is not valid.

A uniform soil model can also be used at high frequency because in that case, the skin effect limits the penetration depth of the electromagnetic field to a few meters and so, the soil resistivity of the depth layers do not affect the results.

The soil structure in general changes both in vertical and horizontal direction.

The vertical changings are usually predominant on the horizontal ones, but to correctly apply this concept it is essential to consider also the grounding system size.

In case of small grounding systems (maximum size up to a few hundred meters), soil model is not significantly affected by horizontal changings in soil resistivity and usually a multilayer soil model is appropriate. The layer number depends on the soil resistivity variations in vertical direction and three or four layers can be sufficient for most cases.

In case of grounding systems of intermediate size, soil model is affected by both horizontal and vertical changings in soil resistivity and usually an equivalent double or triple layer soil model is appropriate. This is the most important case in practical applications.

In case of large grounding systems (maximum size over a few kilometers), soil model is significantly affected by horizontal changings in soil resistivity and usually a multizone soil model is appropriate. The zone number depends on the systems size and soil resistivity variations in horizontal direction.

The use of a multilayer soil model with a great number of layers is important in case of evaluation of seasonal effects on soil model.

3.5 WHEN SEASONAL ANALYSIS IS IMPORTANT?

The seasonal effects can be relevant in particular in cold regions where, during the winter season, superficial soil layers can freeze.

Cold regions are essentially territories at a latitude over 50° North or 50°South or territories with a continental climate, or again, territories with an altitude over 1000 m above sea level (however, this statement must be carefully verified on the basis of local information). The following maps represents the frost penetration depth in North America.




Figure 3-2: Frost penetration depth in the North America in inches (only for reference)

As practical suggestion, the seasonal analysis should be considered in regions where frost penetration depth is significant, for instance more than 0.5 m (20"). This seems reasonable.

The grounding grid should be placed below the maximum frost penetration depth, but in some cases, for instance when this depth is more than 1 m this is not practical. In these cases, the practice is to place grid at 1 m and using drilled vertical rods as auxiliary grounding systems.

Grounding design in very cold regions is anyway challenging.

3.6 WHY THE DOUBLE LAYER SOIL MODEL IS ANYWAY IMPORTANT?

In case of grounding systems of large size, soil model is affected by both horizontal and vertical changings in soil resistivity and usually an equivalent double layer soil model is a good approximation.

The choice of an equivalent double layer soil model is often important for the following simple considerations that even a unskilled user can easily understand.

- The soil resistivity is a parameter that is difficult to know with precision due to several variables:
- The resistivity of the upper layer changes with temperature, rain, pollution ...
- The resistivity of the deep layers changes mainly with the kind of soil
- In case of large sites, horizontal resistivity variation is unavoidable
- In case of large sites, the soil surface often cannot be considered flat

In practical cases, a single soil model is not able to represent a large site, in all places and possible environmental conditions.

Therefore, it is useless to refine soil models that inevitably are correct only in some specific point of the site.

A double layer soil model represents a good approximation because touch and step voltages depend mainly on the resistivity of the upper layer, where the electrode is usually buried, and the lower layers can be represented by one equivalent layer which mainly affects the equivalent resistance of the electrode.

In few words, in general, a double layer soil model is not a compromise but the only reasonable alternative to a uniform soil model.

In the following a true double layer soil model case.

The measurements at different sites indicate about the same model.




Figure 3-3: Soil resistivity measurements in case of true double layer soil model

In the following some false double layer soil model cases.

The measurements at different sites indicate different models.

XGSLab finds the general equivalent double layer soil model.

In these cases, a multilayer soil model with more than two layers usually does not improve the calculation.




Figure 3-4: Soil resistivity measurements in case of false double layer soil model




Figure 3-5: Soil resistivity measurements in case of false double layer soil model

3.7 WHEN IT IS IMPORTANT TO CONSIDER SOIL PARAMETERS FREQUENCY DEPENDENCE?

When frequency is over a few kHz soil resistivity and permittivity frequency dependence effects are not negligible.

When frequency grows, resistivity and permittivity change substantially and is fundamental to consider these effects in order to avoid large calculation errors.

There is not a general consensus about the soil parameter frequency dependence model.

XGSLab consider the following models:

- Messier
- Visacro – Portela
- Visacro – Alipio
- CIGRE TB 781 Model

In time domain calculation involving high frequency spectrum signals, if the soil parameters frequency dependence is neglected, calculation errors could be unacceptable.

3.8 WHY IT IS IMPORTANT A MODEL THAT CONSIDERS BOTH SELF AND MUTUAL IMPEDANCES?

Self impedances cannot be neglected in all systems where physical size is not negligible if compared to the wavelength length.

In practical cases and industrial frequency (50 or 60 Hz) self impedances cannot be neglected when the system size is over a few hundreds of meters.

In same conditions, mutual impedances cannot be neglected in case of large systems when soil resistivity is in the common range from 10 to 100 Ωm .

In general, neglecting self and mutual impedances can lead to very large errors.

Anyway, a parametric study showed that is not sufficient consider self impedances only.

The effect of mutual impedances can be significant and neglecting this parameter, the calculation error can be more than 25%.

In general, effects of self and mutual impedances grow with the grounding system size, with soil conductivity (inverse of resistivity) and with frequency.

3.9 IS IT POSSIBLE MODELING THE SOIL USING SOIL RESISTIVITY MEASUREMENTS?

Yes, it is possible to use both Wenner and Schlumberger resistivity measurements to obtain the soil parameters of uniform and multilayer soil models with an arbitrary layers number.

The on field measurements may be directly entered into the software including information about buried length of probes. The algorithm to obtain soil parameters starting on resistivity measurements is based on the Trust Region Method and is very powerful and accurate and can manage constraints on results (results inside a given range).

3.10 WHAT THE MESSAGES “TOO SHORT ELEMENT” AND TOO LONG ELEMENT” MEAN?

XGSLab works with “thin” elements.

Thin mean that the length of the element must be much greater than its diameter.

In case of bare element, an element is thin if the length is at least 4 times the diameter for a warning message and 2 times for an error message.

In case of covered elements the rule is related to the external diameter out of covering.

Anyway, elements cannot be too long.

The maximum length depends also on the system size and on the wavelength, then on soil resistivity and frequency.

The element length must be lower than “ $\lambda/10$ ” for a warning message and “ $\lambda/6$ ” for an error message.

The User Guide includes many details about that.

Anyway, a correct fragmentation in elements is crucial for the calculation accuracy.

3.11 CAN I CONSIDER SOIL IONIZATION EFFECTS?

XGSLab does not consider directly soil ionization effects.

Soil ionization can appear only in case of small grounding systems (like a system for tower footing) and large currents to earth. In case of medium and large grounding systems (like a substation), this phenomenon can be neglected.

Anyway, it is possible to consider soil ionization effects by increasing the radius of conductors around which the electric field is over the critical value.

The user should perform a preliminary calculation without ionization, then calculate the new radius of conductors around which the electric field is over the critical value and run a second calculation.

The process is iterative but usually one or two iterations can be sufficient for an engineering purpose.

Normally, the ionization effect is quite moderate due to the dependence of the performance of earthing systems on the logarithm of the conductor radius.

3.12 CAN I CALCULATE AN INTERFERENCE WITH SYSTEMS AT DIFFERENT FREQUENCY?

GSA_FD and XGSA_FD can perform calculations using a single frequency at a time.

The possibility to export results in “csv” file can be useful in many cases.

For instance, in case of interference from independent systems with different frequency and the same victim (e.g the same pipeline), the total induced potential can be calculated using the effects superposition. As known, the effects superposition can be applied in linear systems, as usually happen in case of electromagnetic interference related to power lines.

This situation is quite common in Germany, where often, same tower lattices are used for power systems at 50 Hz and railways at 16.7 Hz.

In this case the calculation process can be the following:

- The User can perform a first calculation using the only systems at 50 Hz and then export the potential distribution along victims in numerical form in a “csv” file
- The User can perform a second calculation using the only systems at 16.7 Hz and then export potentials in numerical form in a csv file
- The total induced potential distribution along victims can be calculated using data in the “csv” files and the following equation (EN 50443:2012) for each element of victim

$$U = \sqrt{\sum_{i=1}^n |U_i|^2}$$

where:

- n = number of independent systems with different frequency
- U_i (V) = effective value of the induced potential from system i

3.13 CAN I CALCULATE AN INTERFERENCE BY PARTS AND THEN SUPERPOSE THE EFFECTS?

GSA_FD and XGSA_FD can perform calculations using a maximum number of elements depending also on RAM availability. In case of very large systems, when the maximum number of elements is not enough for a single model, the interference can be calculated by parts and then effects can be superposed.

The possibility to export results in “csv” file can be useful also in this case.

In case of interference from independent systems with same frequency and the same victim (e.g the same pipeline), the total induced potential can be calculated using the effects superposition. As known, the effects superposition can be applied in linear systems, as usually happen in case of electromagnetic interference related to power lines.

In this case the calculation process can be the following:

- The User can perform a first calculation using the only sources part 1 and all victims and then export the potential distribution along victims in numerical form in a “csv” file
- The User can perform a second calculation using the only sources part 2 and all victims and then export the potential distribution along victims in numerical form in a “csv” file
- The total induced potential distribution along victims can be calculated using data in the “csv” files and the following equation (EN 50443:2012) for each element of victim

$$U = \sqrt{|U_1|^2 + |U_2|^2 + 2|U_1||U_2|\cos\gamma}$$

where:

- U_i (V) = effective value of the induced potential from system i
- γ (deg) = angle between induced potentials

In general, the angle between induced potentials is unknown, and conservatively the formula to use is the following:

$$U = \sqrt{|U_1|^2 + |U_2|^2 + 2|U_1||U_2|} = |U_1| + |U_2|$$

Starting from release 10.2 the maximum number of elements has been increased from 16000+ to 32000+.

Then, previous approach by parts can be avoided, but it is anyway useful in case of limited RAM resources.

3.14 DOES XGSLAB CONSIDER THE END EFFECTS?

The modules based on field theory like GSA_FD, XGSA_FD and XGSA_TD are based on short conductors and consider mutual couplings and coefficient of potential using equations valid in the 3D space. Then they consider end effects.

The module NETS is based on circuit theory and consider equations based on the assumption of infinite length conductors, as usual in similar tools like EMTP. Then it does not consider end effects.

The end effects are evident when the assumption of infinite length conductors is not valid, then they depend on length and mutual distance between conductors.

The difference between results with and without taking into account end effects can be relevant (even an order of magnitude and beyond).

This effect is sometimes overlooked and not known to many engineers.

As general rules, equations based on the assumption of infinite length conductors are valid only in case of parallel conductors with a ratio between length and distance more than 50 for an excellent agreement and 20 for a good agreement.

3.15 ON WHICH CALCULATION METHOD XGSLAB IS BASED?

The modules GSA, GSA_FD, XGSA_FD and XGSA_TD are based on electromagnetic field theory (Maxwell equations, Sommerfeld integrals and Jefimenko equations), on mathematical transformations (Fourier transforms) and the numerical method PEEC (Partial Element Equivalent Circuit) in full-wave conditions.

The PEEC is a BEM (Boundary Element Method) developed in about 1990, and allows to simulate systems of conductors integrated with circuit components like generators and impedances.

Many people do not know the difference between BEM and FEM (Finite Element Method) but the difference is crucial.

Essentially with FEM the discretization is applied to the propagation medium, with BEM the discretization is applied to the sources.

FEM is a numerical method for solution of partial differential equations and is really useful in some applications, but hard to use for engineering purposes because the modelling difficulties in case of unbounded scenarios and the hardware requirements.

BEM is numerical method in integral form perfectly suitable for engineering purposes.

All main software in the market like CDDEGS®, WinIGS®, CYME®, ETAP®, ELEK® are based on BEM.

The module NETS is based on circuit theory (graphs theory and Kirchhoff laws), on power lines, cables and transformers theory and the numerical method PCM (Phase Components Method).

Many people know the method SCM (Sequence Component Method) but do not know PCM.

In particular many people do not know the application limits of the SCM.

We used the PCM because this method is for general purposes and can be applied with multiphase and multiconductor systems, symmetrical or not, balanced or not and in particular can consider multiple grounded systems and problems that involve currents to earth.

In general, the SCM cannot be used in case of multiple grounded systems.

WHY SOMETIME POTENTIAL CALCULATED CLOSE TO ELEMENTS IS NOT AS EXPECTED?

The modules GSA, GSA_FD, XGSA_FD and XGSA_TD are based on the PEEC numerical method.

The system of conductor is divided in short elements.

With a first calculation step, the program determines charges, currents and potentials on each element.

With a second calculation step, the program determines potentials and fields in the propagation medium as superposition effects of all elements.

The calculation of potentials assumes a uniform charge distribution (or leakage current distribution) along each element.

As a consequence, the potential close to the elements will not be uniform and then will be in general different from the actual element potential.

The potential distribution related to a uniform charge distribution in a single element can be represented using ellipsoids in the 3D space.

Far away from the elements these ellipsoids become spheres and calculation is as expected. But close to the elements potential distribution differ from ellipsoids and there are no analytical equations to express them.

XGSLab use algorithms that gradually correct the potentials very close to the elements by forcing their value to the known one.

These algorithms work well very close to the elements, while far to the elements no correction is necessary.

There is a transition zone where algorithms do not work.

In this intermediate zone potential could be not as expected, in some condition also more than the potential of the closest element.

The problem is limited to some specific conditions and close to the elements.

3.16 IS IT POSSIBLE IMPEDANCE TO EARTH INCREASES WHEN SYSTEM SIZE INCREASES?

Yes, this is unexpected but possible when the system size is comparable or bigger than the electromagnetic wavelength in the propagation medium.

At low frequency, when soil permittivity effects are negligible if compared to resistivity effects, the electromagnetic wavelength can be calculated using the following formula:

$$\lambda = 3162 \sqrt{\frac{\rho}{f}}$$

where:

– λ (m) = wavelength

- ρ (Ωm) = soil resistivity
- f (Hz) = frequency

For instance:

- If $f = 100$ kHz and $\rho = 100$ Ωm , $\lambda = 100$ m
- If $f = 10$ kHz and $\rho = 100$ Ωm , $\lambda = 316.2$ m
- If $f = 1$ kHz and $\rho = 100$ Ωm , $\lambda = 1000$ m
- If $f = 100$ Hz and $\rho = 100$ Ωm , $\lambda = 3162$ m

Considering a simple system with a single wire and injection point located at an end, the behaviour is the following:

- The impedance decreases when length increase and length is much shorter than wavelength
- The impedance increases when length increase and length is comparable to wavelength
- For even greater lengths the behaviour is oscillating but damped by the dissipative medium

3.17 IS IT POSSIBLE TO REPRESENT CONCRETE ENCASED CONDUCTORS?

Yes, this is possible, but it is important to consider different opinions in literature.

You could avoid to represent the concrete. The buried concrete is hygroscopic and tends to attracts moisture and salts from surrounding soil, and with time (years) the concrete resistivity becomes similar to the soil resistivity.

The other option is to consider the concrete as a cylindrical shell around buried conductors. The shell thickness is usually in the range 3 - 5 cm and represents the minimum concrete thickness between conductors and soil.

The problem is how to fix the concrete resistivity value. IEEE Std 80-2013 states that the common value of concrete resistivity is in the range 30 – 200 Ωm , so a quite wide range. If you consider an average value of concrete resistivity 100 Ωm , you can understand that concrete give advantages in resistance to earth only if the surrounding soil resistivity is less than 100 Ωm , so quite low.

You can easily add a concrete shell to conductors as in the following.

You can create a new conductor and set the coating parameters using concrete.




Figure 3-6: Conductor properties

After that, you can set the conductor you want to consider as concrete encased with the specific created new conductor.

3.18 CAN I CONSIDER ADDITIONAL RESISTANCES IN IEEE STANDARDS LIMITS?

As known, IEEE 80 Standard does not consider hand and foot contact additional resistances, and this is a conservative assumption. This is the reason why, with IEEE 80 Standard and old XGSLab releases, the User could not set the additional parameters “R_{sh}” and “R_{gl}”.

In new XGSLab releases, this constraint has been removed. This because the IEEE 2778 Standard “IEEE Guide for Solar Power Plant Grounding for Personnel Protection” allows to consider additional shoe and glove resistance. These additional resistances can be easily taken into account by setting “R_{sh} (Ω)” (resistance of a single shoe) and “R_{gl} (Ω)” (resistance of a single glove) in the panel for the calculation of Touch and Step Voltages Limits (see figure below).




Figure 3-7: Touch and Step Permissible Voltages

The prospective permissible touch and step voltages with additional resistances (below indicated with a symbol +) without and with soil covering layer (SCL) are calculated by using the following equations:

$$U_{stp+} = (R_b + R_f/2 + R_{sh}/2 + R_{gl}) I_b$$

$$U_{ssp+} = (R_b + 2R_f + 2R_{sh}) I_b$$

$$R_f = \frac{\rho_e}{4b} = \frac{\rho_e}{4 \cdot 0.08} = 3.125 \rho_e \text{ without SCL}$$

$$R_f = \frac{C_s \rho_s}{4b} = \frac{C_s \rho_s}{4 \cdot 0.08} = 3.125 C_s \rho_s \text{ with SCL}$$

where:

- R_b (Ω) = body resistance
- R_f (Ω) = ground resistance of one foot
- R_{sh} (Ω) = additional resistance of a shoe
- R_{gl} (Ω) = additional resistance of an insulating glove
- I_b (A) = tolerable body current
- ρ_e (Ωm) = ρ_e or ρ_1 for uniform or multilayer soil model respectively
- ρ_s (Ωm) = soil covering layer resistivity
- C_s = reduction factor related to the soil covering layer

– b (m) = equivalent radius (0.08 m)

The relation between permissible touch and step voltages with and without additional resistances is the following:

$$U_{stp+} = U_{stp} + (R_{sh} / 2 + R_{gl}) I_b$$

$$U_{ssp+} = U_{ssp} + 2R_{sh} I_b$$

For instance, if $t_f = 0.5$ s and Body Weight = 50 kg, $I_b = 0.164$ A, $U_{stp} = 189.7$ V and $U_{ssp} = 266.6$ V.

If the resistance of a single shoe is 2000 Ω and no gloves are considered, the new permissible touch and step voltages will be respectively:

$$U_{stp+} = 189.7 + (2000/2) * 0.164 = 353.7 \text{ V}$$

$$U_{ssp+} = 266.6 + 2 * 2000 * 0.164 = 922.6 \text{ V}$$

3.19 CAN I USE LIBRARIES IN MY COMPUTER IN OTHER COMPUTERS?

The simplest way to do that is to open a project (let us call it "NewItemsPrj") that has those new items you are interested in, in the computer (let us call it "2ndPc") in which you want to carry the new items.

Once you have opened NewItemsPrj in 2ndPc you have to go to this section:




Figure 3-8: Commit and Update menu options

If you click on "Commit" you make the new items present in the data base of NewItemsPrj available also for all the future projects that will be created in 2nd Pc.

Moreover, once executed the “Commit”, if you want to have the new items also in a project (let us call it “OldPrj2ndPc”) created before the commit, you have to open OldPrj2ndPc and click “Update” in the section of the main tool bar circled in the picture here above.

Pay attention to these constraints:

- The same description cannot be used twice
- The same properties can be set for different description

These conditions have been introduced recently and they face databases built with old and more “relaxed” constraints. This implies that it is very likely you will find a message like this.




Figure 3-9: Error message

In case this message pops up there are two alternative ways to overcome it:

- Rename the record(s) pointed out (in the picture here above “fence post” in the “conductor library”)
- Delete the record(s) pointed out

Finally consider also that, at the moment, when you update the software, the database of libraries is again the initial one. To make it contain all the customizations you did in the past you have to open a project created before the updating of the software and execute a commit from there.

3.20 WHAT IS THE MAXIMUM NUMBER OF LAYERS IT IS POSSIBLE TO CALCULATE?

Usually, soil resistivity measurements are based on Wenner and Schlumberger methods.

The apparent soil resistivity can be calculated from measurement using the following equation:

$$\rho_m = \frac{2\pi R}{\frac{1}{c} - \frac{1}{a+c} + \frac{1}{\sqrt{c^2 + 4b^2}} - \frac{1}{\sqrt{(a+c)^2 + 4b^2}}}$$

where:

- R (Ω) = Wenner or Schlumberger resistance
- a (m) = spacing between voltages probes
- b (m) = probes depth
- c (m) = spacing between voltages and current probes (in case of Wenner method c = a)

The apparent soil resistivity can be calculated also starting from the soil model parameters.

For instance, for a multilayer soil model it is possible to calculate:

$$\rho_c = \rho_c(a, c, \rho_1, \rho_2, \dots, \rho_n, h_1, h_2, \dots, h_{n-1})$$

where:

- a (m) = spacing between voltages probes
- c (m) = spacing between voltages and current probes
- ρ_i (Ωm) = resistivity of layer i
- h_i (m) = thickness of layer i

The calculation of layer parameters (resistivity and thickness) can be done using a minimization algorithm which lead to the minimum of the following squared error function:

$$\psi(\rho_1, \rho_2, \dots, \rho_n, h_1, h_2, \dots, h_{n-1}) = \sum_{i=1}^N \left[\frac{\rho_m(a_i, c_i) - \rho_c(a_i, c_i, \rho_1, \rho_2, \dots, \rho_n, h_1, h_2, \dots, h_{n-1})}{\rho_m(a_i, c_i)} \right]^2$$

where:

- a (m) = spacing between voltages probes
- c (m) = spacing between voltages and current probes
- ρ_i (Ωm) = resistivity of layer i
- h_i (m) = thickness of layer i
- N = number of measured resistivity values

Previous equation can include weight functions, but this is not essential for the following considerations.

The number of unknowns in previous minimization problem is P, a resistivity and a thickness for each layer except the bottom layer with infinite depth. It follows:

$$P = 2L - 1$$

where:

- L = number of layers

As known, in case of a linear system, the number of independent equations must be the same of the unknown.

In the specific case, the minimization algorithm can find also more unknowns than equations, but in XGSLab the following conservative checks has been implemented:

- If the number of independent measurements N is lower than 2P, the following message is shown "Warning: poor number of measurements with different electrode spacings". In this case the calculation is done
- If the number of independent measurements N is lower than P, the following message is shown "Error: insufficient number of measurements with different electrode spacings". In this case the calculation is not done

Independent measurements mean Wenner and Schlumberger measurements with different electrode spacings.

For instance, if $L = 5$, $P = 9$ and then, the minimum number of independent measurements is 9, the minimum suggested number of independent measurements is 18.

3.21 CAN I DO CALCULATIONS IN THE TIME DOMAIN USING AN EQUIVALENT FREQUENCY?

Based on German literature, by using the frequency domain approach and an equivalent single frequency input it is possible to obtain similar results than with a time domain approach. The equivalence between impulse and sinusoidal wave forms means that, the maximum values of the two wave forms are the same for engineering perspective. As known, for the calculation of touch and step voltages, induced voltage, electrodynamic forces, dielectric effect (flashover/cracking) applications, it is sufficient to consider the peak value of the current.

Otherwise, people usually believe, the lightning is a phenomenon at relatively low frequency. The equivalent frequency of a standard lightning with front time to peak value “ T_1 ” can be calculated as follows:

$$f_{eq} = \frac{1}{4T_1}$$

where:

- f_{eq} (MHz) = equivalent frequency
- T_1 (μ s) = front time to peak value

The effective value of the sinusoidal wave form has to be calculated assuming that the maximum values of impulse and sinusoidal wave forms are the same. For instance, the equivalent sinusoidal wave form of a impulse corresponding to a fort positive stroke with $I_{peak} = 100$ kA and $T_1/T_2 = 10/350$ μ s has an effective value 70.7 kA and a frequency 25 kHz. The front steepness of the sine currents is around 12 % higher than the corresponding Heidler function.

The equivalent frequency for a first negative stroke with $T_1/T_2 = 1/200$ μ s is 250 kHz.

The equivalent frequency for a subsequent negative stroke with $T_1/T_2 = 0.25/100$ μ s is 1 MHz.




Fig. 3-10: Comparison between Heidler function and the equivalent sinusoidal wave form

The results of the calculations with the equivalent sinusoidal wave form have to be compared with limits related to the same frequency. There are not enough studies about the life hazard caused by lightning effects on the human body and as consequence in the international standard there are not touch and step voltages as for the low frequency.

The reference literature is essentially the following:

Rock, M.; Zischank, W.; Kupfer, J.: Grenzwerte für Schritt- und Berührungsspannungen an Blitzschutz-Ableitungseinrichtungen und –Erdungsanlagen. 11. VDE/ABB-Blitzschutztagung, Neu-Ulm, 2015.

Suchanek, S.: Auswirkungen von Schrittspannungen auf den Menschen (Effects of step voltages on the human Body). 9. VDE/ABB-Blitzschutztagung, 27. – 28. Oktober 2011 in Neu-Ulm.

Permissible touch voltage corresponding to a human body resistance 1 kΩ and a specific energy sufficient to produce ventricular fibrillation $W/R = 0.001 \text{ A}^2\text{s}$ or $W = 1 \text{ Ws}$ are the following:

	10/350	1/200	0,25/100
U_{TP}	2 kV	2,65 kV	3,75 kV
I	2 A	2,65 A	3,75 A

Tab. 3.1 – Peak of the permissible touch voltage at high frequency or impulse

Permissible step voltage corresponding to a human body resistance 1 kΩ and a specific energy sufficient to produce ventricular fibrillation $W/R = 0.156 \text{ A}^2\text{s}$ or $W = 156 \text{ Ws}$ are the following:

	10/350	1/200	0,25/100
U_{SP}	25 kV	33 kV	47 kV
I	25 A	33 A	47 A

Tab. 3.2 – Peak of the permissible step voltage at high frequency or impulse

Effective value can be calculated simply dividing by $\sqrt{2}$. For instance, the touch and step permissible effective value at 25 kHz can be respectively $2000/\sqrt{2} = 1414 \text{ V}$ and $25000/\sqrt{2} = 17730 \text{ V}$.

Values at intermediate frequencies can be interpolated.

3.22 HOW CAN I PROPERLY SET THE “RAM SAVING” THRESHOLD?

With *_FD it is also possible to set the threshold of elements number “n” above which a RAM saving calculation option is adopted in the general linear system solution.

If the elements number is below the “RAM Saving” threshold the program uses a single step solver.

If the elements number is above the “RAM Saving” threshold the program uses a double step solver.

XGSLab employs a user-defined "RAM Saving" threshold (default 10000 elements) to decide between two solvers.

The User can modify this parameter from 1 to a value set as below described.

Here's a summary of the two solver.

Single-Step Solver (below Threshold):

- Used for systems with element count below the threshold
- More efficient and accurate
- Works directly with the entire "2n" order system, requiring significant RAM proportional to "2n x 2n"

Double-Step Solver (above Threshold):

- Activated for systems exceeding the element threshold
- Less efficient and potentially less accurate due to additional computations
- Conserves memory by splitting the "2n" order system into two smaller "n" order equations
- Solves using these smaller systems "n x n"
- Requires less memory proportional to "n x n" but involves matrix inversion and multiplications, impacting efficiency

Trade-off:

- Single-step (elements number below the "RAM Saving" threshold) offers superior speed and accuracy but demands more memory
- Double-step (elements number above the "RAM Saving" threshold) saves memory but comes at the cost of potential performance and accuracy drawbacks, especially for specific element types

Important Note: the threshold applies to the total number of elements for GSA_FD and XGSA_TD calculations, but to the victim element count for XGSA_FD.

It is clear that where possible it is always advisable to use the single step solver.

To correctly set the "RAM Saving" threshold it is important to know the available RAM.

Note the available RAM, the maximum "RAM Saving" threshold can be obtained from the INSTALLATION GUIDE Figure 2-1 RAM requirements – grey curve (repeated below for convenience).




Fig. 3-11: RAM requirements

For instance, if available RAM = 128 GB, the maximum "RAM Saving" threshold is about 20000 elements.

3.23 WHAT IS THE MAXIMUM HEIGHT OF STRUCTURES SHIELD CAN CONSIDER?

SHIELD essentially does not consider lateral lightning strokes.

IEC Standards states that the probability for flashes to the sides is generally negligible for structures up to 60 m high.

In some particular circumstances, if the structure to be protected is very high and with significant protrusions such as balconies or viewer platforms, the rolling sphere can go under the lightning protection system.

Of course, this can happen only if lateral lightning may occur.

For these reasons, SHIELD is suitable for structures of any height or up to 60 m height in case of relevant protrusions.

For special structures with height over 60 m and relevant protrusions, such as balconies or viewer platforms, or in case of wind towers, the right module to use is SHIELD_A. In essence, SHIELD_A was developed for all applications where SHIELD cannot be used, and is intended to be complementary to SHIELD.

4. DEMO FAQ

Get more information about presentations and demo versions.

4.1 CAN I HAVE A WEB BASED PRESENTATION OR A DEMO VERSION?

Both options are possible.

According to our experience a web-based presentation can be more effective than a demo in showing XGSLab features in a short time.

It is possible to ask for a web presentation to our Customer Service at sales@xgslab.com.

By the way, you can require also a demo application to us.

Demo version is useful for Users familiar with similar tools.

Demo version is available as online and keyless license, it is limited in time and features but can be useful to try XGSLab.

4.2 HOW TO ACTIVATE CAMEYO ONLINE DEMO?

When your demo request has been processed, you receive the email below:




Figure 4-1: Welcome mail with link

Click on “Start XGSLab” in order to test XGSLab on web browser.

Wait a few seconds until program is loaded.




Figure 4-2: XGSLab on Browser

The demo version can use existing tutorial projects.

These projects can be opened, used and saved in your PC.

Tutorial Projects are located on: Documents\XGSLab\Projects

In order to save a file use function “Download” on Desktop area.

In order to load a file “Upload” it from Desktop.

There is no persistence, meaning whatever the user does to the projects in one session does not follow to the next session.

The original projects cannot be modified by users.

When a user section terminates all data on server will be removed, so download your project before closing.




Figure 4-3: Desktop for saving new test projects

4.3 HOW TO IMPORT EXTERNAL FILES IN THE CAMEYO ONLINE DEMO?

The demo version can load external dxf files.

Shortly, you can follow the following steps:

- 1) Create a Project
- 2) Click on menu “Import and Export”
- 3) Set a “dxf” file in the “Path” box (click on folder icon)
- 4) Drag the file in the select “Drag and Drop” folder and confirm ...

In order to import external file in the application (eg. dxf) or export file project use these instructions:

You can click \\tsclient\Storage, which is pinned to Quick access, and will be taken directly to where uploaded files are.




Figure 4-4: Import of external files – Step 1

Then you have to select “All files (*.*)” as file type to be able to see




Figure 4-5: Import of external files – Step 2

Now you have to drag and drop in the \\tsclient\Storage folder the file you are interested in
 Finally, you can right click in the files area and click Refresh instead in order to be able to view the dragged file.




Figure 4-6: Import of external files – Step 3